



安全·簡単·便利

## Rust&Scale Remover-2 Strong

RSR-2 removes even heavy rust in 30 seconds

1kg・850ml入り





## <Application>

- Removal rust from motorcycle fuel tank
- Removal rust from vintage car & classic car
- Removal rust from metallic part and screws
- Cleaning of tools and weapons
- Cleaning of machines such as food processing machines
- Cleaning of rust stains
- Scale removal from pipes
- Cleaning of heat exchanges
- Cleaning of materials in coating factories
- Cleaning of pipes in hot springs
- Cleaning of toilet stains
- Removal of oxidized film
- Peel surface of concrete wall off building
- Wash parts of weld with RSR-2
- Removal of rust and scales from kitchens

<Direction>

- Rust is removed easily by only immersing in RSR-2
- Not necessary to rub or polish. Just wash with tap water afar removing rust.
- ■You can brush or spray on the RSR-2 for big objective.
- ■RSR-2 never attacks original metal, rubber, Chromium & Nickel plating no matter how long it is immersed.
- (It may melt or change color if the objective is low purity Chromium & Nickel plating.)
- ●Use gloves when handling RSR-2; it may infiltrate skin with wounds. You can dilute RSR-2 with water and dispose of the solution in a drain after use.
- ♦It may take a few hours to get rid of rust, depending on grade of rust. RSR-2 is a strong acid, originally pH1. Hence it will be necessary to neutralize the liquid first if it is still effective and especially if it has to be disposed of in a large quantity.

## < Caution >

- ★RSR-2 may melt soft vinyl and nylon stocking upon contact.
- ★RSR-2 may slightly melt containers made of materials such as aluminum, tin and zinc due to its restraining effect.
- ★Stainless steel might be discolored. As such, it is necessary to find the suitable dilution rate before use.



Carefully read the directions label before use.

<Ingredient>Fruit citrates acid/Special high grade vegetable fatty oil Nonionic amphoteric surfactants

ご注文は 電話・FAX・e-mailにて



平和バイオテクニカル(株) 東京都江東区東雲1-9-19-1011

Phone03-6662-8058 fax03-6662-8068 e-mailアドレス info@bio520.co.jp

使用方法・ご質問などお気軽にお尋ねください。電話03-6662-8058 ホームページアドレス http://bio520.co.jp